



DCI, Inc. – Corporate Offices
600 North 54 Avenue (56303)
P. O. Box 1227 (56302-1227)
St. Cloud, MN
Phone: 320-252-8200
Fax: 320-252-0866
Web: www.dciinc.com
Email: sales@dciinc.com

DCI, Inc. is proud to announce the **DCI Upward Spray Cleaning System**.

The new system, with primary and secondary internal vent lines, performs all CIP (Clean-in-Place) operations without requiring access to the top of the tank. To the customer, this means a cost savings, as the additional **purchase of external ladders, walkways, and cages is eliminated**.

An added savings benefit of the internal lines is the **elimination of insulation and heat tape** for the lines; lines are internal and therefore are always the same temperature as the tank.

Other advantages to the new Upward Spray system are a more compact design as well as ease of use. Due to the internal lines, alcove size is made shallower, allowing **customer space savings in their facility**. The **system remains in the tank**--no removal is required between CIP cycles.

The design is currently available in sizes ranging up to 40,000 gallon silo tanks; additional sizes are available upon review of customer specifications. The Upward Spray system is USDA accepted for use in 3-A silos tanks.

While DCI still offers its traditional CIP design, we are pleased to add yet another option to our line of quality products.

